








Customer Service

() 1-800-618-6798

ASSEMBLY GUIDE

Model: CFB2001



Double Sack Crawfish Boiler

FOR YOUR SAFETY!

Use outdoors only! Do not use it inside a building, garage, or any other enclosed space.

Read the instructions before assembling and using the appliance.

DO NOT use the appliance unless it is completely assembled, and all the parts are securely fastened.

This appliance will become very hot, do not move it during use.

Keep children and pets away.

CONTACT US FIRST!

This appliance has been made to high quality standards.

If you have any questions that are not addressed in this Owner's Manual, or you need parts, please call our customer service hotline or send an email to service@creolefeast.com Please keep this Owner's Manual for future reference.


Learn more at:

www.creolefeast.com



Parts Diagram

Cr<u>eole</u> Feast





Ref	Description	Illustration	QTY	Ref	Description	Illustration	QTY
1.	Boiler body ZH-CFB2001001 ZH-CFB2001002 ZH-CFB2001003		1	19.	Caster W-CFT2018009		2
2.	Front boiler frame ZH-CFB2001004		1	20.	Cart connector H-CFT2018036		1
3.	Left side handle ZH-CFB2001008		1	21.	Extension beam ZH-CFT2018020		1
4.	Lid handle W-CFB02001		2	22.	LP cylinder carrier ZH-CFT2018022		1
5.	Front table bracket (L) z-A1CT1005		1	23.	Base panel z-CFB2001024		1
6.	Front table joint (R) z-CFT2018062		1	24.	Burner bracket set with regulator ZH-CFB2001010		1
7.	Front table joint (L) z-CFT2018061		1	25.	Short electrode burner ZH-CFB2001011		1
8.	Handle W-CFB1001004-4		1	26.	Long electrode burner ZH-CFB2001012		1
9.	Paddle W-CFT2018017-1 W-CFB1001004-2		1	27.	Front table z-CFB2001016		1
10.	Cart ZH-CFB2001007		1	28.	Front table bracket (R) z-A1CT1004		1
11.	Paddle bracket z-cfb02019		2	29.	Front thermal baffle z-CFB2001011		1
12.	Valve thermal baffle z-CFB2001012		1	30.	Back boiler frame ZH-CFB2001005		1
13.	Leg base H-CFB1001030		2	31.	Right thermal baffle z-CFB2001013		1
14.	Wheel W-CFB1001021		2	32.	Boiler support beam		2
15.	Wheel axle w-CFB02018		1	33.	Lifting handle W-CFT2018010		2
16.	Side panel (R) z-CFB2001033		1	34.	Back right handle z-CFB2001031		1
17.	Ignitor DQ404+EGRB-DHQ		1	35.	Back left handle z-CFB2001030		1
18.	Hose holder H-CFT2018032	P. S.	1	36.	Side panel (L) z-CFB2001023		1



Α	M6x15	26 pcs	В	M6x35	14 pcs	С	Split pin	2 pcs	D	Sleeve	2 pcs	Е	M5x12	10 pcs
											ı)
F	M4x12	8 pcs	G	M6x15	8 pcs	Н	M6	4 pcs	I	М6	5 pcs	J	Wing bolt	3 pcs
)					*				•
K	Split pin	2 pcs	Г	Pin	1 pc	М	Pin	1 pc	Z	Sleeve	2 pcs	0	Washer	2 pcs
							0)	1					$\mathscr{O} \odot$	


TOOLS REQUIRED				
Description	lmage			
Phillips screwdriver				
Wrench				

Before beginning assembly, make sure all parts are present. If any parts are missing or damaged, do not attempt to assemble the products. Contact customer service for replacement parts via telephone or email.


- Tools needed (not included): Phillips screwdriver and wrench
- Approximate assembly time: 40 minutes
- Note: The right and left sides of the boiler are designed as if you are facing the front of the boiler.



A 🍇 ×4




С		×2	
D	00	×2	
O	0 0	×2	
Ν		×2	













Е	~ ⊕	×2
Α		×4



































10 B ► ×3



















Н ×4 • G ×4




16 • ×4












18 I ►®⊕ ×4









20 A ► *2

































L	×1
K	×1

